

**TITLE OF INVENTION**

### Recessed Step

### CROSS REFERENCES TO RELATED APPLICATIONS

Not Applicable

**STATEMENT REGARDING FEDERALLY SPONSORED RESEARCH**

Not Applicable

## REFERENCE TO APPENDIX

Not Applicable
----------------

## BACKGROUND OF THE INVENTION

**FIELD OF THE INVENTION:**

This is a device, which will allow the user to "add" a step in needed situations such as hard to reach places in the kitchen, or closets. The step is portable and easily stowed when not in use.

**PRIOR ART:**

The prior art in this area reveals that there are a variety of means to add a step in certain applications. These can be attached to cabinets such as Caminiti, patent number 5,131,492 or drawers as in Gaede, patent number 3,481,429. Additionally, there are fold away steps, Horvath, patent number 3,136,386.

While these are indeed similar ideas, they are permanently attached or affixed to an object.

This device is a portable additional step, which can be moved from location to location and provides the user with greater flexibility in terms of ease of access and utility.

## BRIEF SUMMARY OF THE INVENTION

One of the difficulties in the home or business is reaching overhead areas. People stand on chairs, footstools and the like to reach these difficult areas.

This device combines the utility of a step with portability so that the device will not clutter up the home or be a traffic hazard in a kitchen or garage.

The device will provide another step, which will raise to a level of approximately six to eight inches above the level of the rest of the device. The additional step is raised by use of a hinge mechanism, which has been placed on the outside edges of the step. This is not a step stool because it can be stored under a cabinet or in its own storage place and hidden from view.

It is a portable unit that allows the user to have within his or her grasp a device, which will add an additional step wherever one may be needed. The device is in the shape of a hollow, rectangular box. In the approximate middle of the device is a piece of wood with a hole in the middle. This piece of wood rotates up and down and provides the additional step.

The hole in the center of the piece allows the owner to carry the device from location to location with relative ease. The step - when in the down position - will remain flush with the rest of the unit and can be used as a platform. The device

1 when used as a platform is raised off the ground approximately  
2  
3 six to eight inches. The step is raised and lowered by two  
4  
5 sets of hinges, which are connected to the step and to one side  
6  
7 of the rectangular box.  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50

**BRIEF DESCRIPTION OF THE DRAWINGS**

Figure 1 is a perspective view of the device with the added step in the raised position.

Figure 2 is a perspective view of the device with the added step flush with the top of the device.

Figure 3 is a cross sectional view of the device showing the step in the raised position.

Figure 4 is a cross sectional view of the mechanism to support the step.

Figure 5 is a view showing the articulation of the hinge.

## DETAILED DESCRIPTION OF THE EMBODIMENT

This particular device 50 is in the shape of a rectangular box or frame. The device is comprised of a flat planar surface 100 with a step 200 which can be raised and lowered approximately six to eight inches. Figure 1 shows the perspective view of the device with the step 200 in the "up" or raised position. On one end of the rectangular box is the flat surface 100, which is permanently affixed to approximately one third of a portion of the top of the rectangular box. The flat surface 100 allows the person to step on the device 50 and then step on the additional step 200, which is provided.

In the center of the device is the recessed step 200, which rotates around a nut and bolt assembly, 400, 410, on both sides of the bottom surface of the recessed step 200. Figure 4 The nut and bolt assembly 400, 410 are attached to the device with hinges 300 on both sides of the step. Figure 3 The device will give the person an additional six to eight inches when the step 200 is in the "up" position.

In the "down" position the recessed step 200 lies flush and parallel with the flat planar surface 100. Figure 2 This allows easy storage of the device 50.

A hole 250 in the middle of the recessed step 200, which is raised or lowered, allows the user to carry the device from place to place and stow it wherever desired. When the step 200 is "down" the device 50 can be slid under a couch or stowed

1 between appliances. This keeps the device 50 out of the way of  
2 the homeowner. Figure 2 shows the step in the "down" position.

3  
4 Figure 2 is a perspective view showing the position of the  
5 step 200 and the other flat planar member 100 lying flush with  
6 the step 200. The recessed step 200 will rotate in an "up" or  
7 "down" direction and is supported by a hinge 300 and a stop  
8 mechanism 310 on both sides of the step. Figure 3 The hinge 300  
9 and stop mechanism 310 allows the additional step 200 to be  
10 raised and lowered to the desired height. Hinges 300 are  
11 located on both sides of the recessed steps to secure the step  
12 to the device.

13  
14 The hinge 300 as depicted in Figure 3 is supported by a  
15 bolt and nut assembly 400, 410, which is connected to the step  
16 200 and the wooden frame of the device 50. Figure 4 The hinges  
17 300 are located at the approximate midpoint of the recessed step  
18 200 and the side member of the rectangular box. While a nut and  
19 bolt assembly 400, 410 is depicted in Figure 3, other means of  
20 attachment may be used to achieve the same purpose. The nut and  
21 bolt assembly 400, 410 as depicted in Figure 5 is recessed  
22 slightly to allow freedom of movement of the step 200 from the  
23 up to down position and vice versa.

24  
25 The stop mechanisms 310 are positioned so that the step 200  
26 rotates to a position slightly greater than ninety degrees from  
27 the vertical plane. This angle will insure that the step 200  
28 stays in place as it rotates upward to approximately one hundred  
29  
30

1 and ten degrees from the vertical plane of the device. The  
2  
3 degree of rotation of the step 200 in relation to the horizontal  
4  
5 plane allows the step to be raised and stay in an upright  
6  
7 position without the necessity of a separate hinge or other  
8  
9 locking device.

10  
11 The step 200 is prevented from rotating more than  
12  
13 approximately one hundred and ten degree by the stop mechanism  
14  
15 310, which has been placed adjacent to the hinge 300. Figure 3  
16  
17 The stop mechanism 310 is positioned on the inner surface of the  
18  
19 device and will prevent the step from rotating any more than  
20  
21 approximately one hundred and ten degrees. Both inner surfaces  
22  
23 of the device are equipped with the stop mechanism 310 at the  
24  
25 location of the step 200.

26  
27 The choice of material will be selected so that the device  
28  
29 will be able to support an adult and be durable for that  
30  
31 purpose.  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50